




FIG.1



2 / 12

FIG.2





FIG.3



3 / 12

FIG.4




FIG.5




FIG.6

REMOTE VEHICLE POSITION
REQUEST MESSAGE

OPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID
-----	--------------------------	-------------------------

OPR : REMOTE VEHICLE POSITION
REQUEST CODE

FIG.7





FIG.8

VEHICLE POSITION SPONTANEOUS
TRANSMISSION MESSAGE

CPT	ORIGINATING VEHICLE ID	DESTINATION VEHICLE ID	VEHICLE POSITION INFORMATION
-----	---------------------------	---------------------------	---------------------------------

CPT : VEHICLE POSITION
SPONTANEOUS TRANSMISSION CODE

FIG. 9



7/12

FIG.10

VEHICLE POSITION
REQUEST MESSAGE

CPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER
-----	--------------------------	-------------------------	-------------------

CPR : VEHICLE POSITION REQUEST CODE


FIG.11

RETURN VEHICLE
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	VEHICLE POSITION INFORMATION
-----	--------------------------	-------------------------	----------------------	---------------------------------

RCP : RETURN VEHICLE POSITION CODE

FIG.12



9 / 12

FIG.13

RETURN VEHICLE
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR1
-----	--------------------------	-------------------------	----------------------	------

RCP : RETURN VEHICLE POSITION CODE

ERR1 : FIRST ERROR CODE

FIG.14

RETURN VEHICLE
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR2
-----	--------------------------	-------------------------	----------------------	------

RCP : RETURN VEHICLE POSITION CODE

ERR2 : SECOND ERROR CODE

REMOTE VEHICLE POSITION DISPLAY ROUTINE




FIG. 16




FIG. 17

